# Alphabetical index Alphabetical index

Α	A/C	232
	ABS	.200
	ACCESSORY mode	139
	Active stabilizer suspension	
	system	. 200
	Adaptive variable	
	suspension system	199
	Air conditioning system	
	Air conditioning filter	451
	Automatic air conditioning	
	system	232
	Airbags	
	Airbag operating conditions	98
	Airbag precautions for	
	your child	102
	Airbag warning light	492
	Curtain shield airbag	
	precautions	105
	General airbag precautions	102
	Locations of airbags	95
	Modification and disposal of	
	airbags	106
	Proper driving posture	93
	Side airbag precautions	102
	Side and curtain shield airbags	
	operating conditions	98
	SRS airbags	95
	Alarm	90
	Antenna	250
	Anti-lock brake system	. 200
	Armrest	371
	Ashtrays	366

Audio system	
Antenna	250
AUX adapter	302
Cassette player	253
CD player/changer	257
DVD information	
DVD player/changer	266
DVD video/audio	269
MP3/WMA disc	262
Optimal use	297
Radio	
Steering switches	303
Video CD	
Automatic headlight leveling	
system	160
Automatic light control system	
AUX adapter	
Back-up lights	
Back-up lights Wattage	
Wattage	
WattageBattery	552
WattageBattery  12 volt battery	552
WattageBattery  12 volt batteryChecking	552
Wattage  Battery  12 volt battery  Checking  Hybrid battery	552 430 430
Wattage Battery  12 volt battery Checking Hybrid battery  (Traction battery)	552 430 430
Wattage Battery  12 volt battery Checking Hybrid battery (Traction battery) If the 12 volt battery is	552 430 430
Wattage  Battery  12 volt battery  Checking  Hybrid battery  (Traction battery)  If the 12 volt battery is  discharged	552 430 430
Wattage  Battery  12 volt battery  Checking  Hybrid battery  (Traction battery)  If the 12 volt battery is  discharged  Preparing and checking	552 430 430 26
Wattage  Battery  12 volt battery  Checking  Hybrid battery  (Traction battery)  If the 12 volt battery is  discharged  Preparing and checking  before winter	552 430 430 26 534
Wattage  Battery  12 volt battery  Checking  Hybrid battery  (Traction battery)  If the 12 volt battery is  discharged  Preparing and checking  before winter	552 430 430 26 534
Wattage  Battery  12 volt battery  Checking  Hybrid battery  (Traction battery)  If the 12 volt battery is  discharged  Preparing and checking  before winter  Bluetooth®  Brake	552 430 26 534 215
Wattage  Battery  12 volt battery  Checking  Hybrid battery  (Traction battery)  If the 12 volt battery is  discharged  Preparing and checking  before winter	55243026215311429

С	Care
	Exterior402
	Interior405
	Seat belts406
	Cargo capacity210
	Cargo hooks375
	CD player/changer257
	Chains216
	Child-protectors51
	Child restraint system
	Definition113
	Installation117
	Installing CRS with lower
	anchors121
	Installing CRS with seatbelts 118
	Installing CRS with top straps123
	Child safety
	Airbag precautions102
	Battery precautions432, 537
	Child restraint system113
	Child-protectors51
	How your child should wear
	the seatbelt69
	Installing child restraints117
	Moon roof precautions82
	Power window lock switch77
	Power window precautions79
	Removed electronic key battery
	precautions455
	Seat belt comfort guide67
	Seat belt precautions70
	Seat heater precautions 370
	Trunk precautions57
	Cigarette lighter367

	Cleaning	
	Exterior402	
	Interior405	
	Seat belts406	
	Clock364	
	Coin holder360	
	Compass383	
	Condenser428	
	Console box357	
	Cooling system	
	Engine overheating538	
	Cruise control	
	Cruise control166	
	Dynamic radar cruise control 169	
	Cup holders360	
	Curtain shield airbags95	
	Customizable features569	
D	Daytime running light system	
	Defogger	
	Rear window240	
	Side mirror240	
	Dimension544	
	Dinghy towing221	
	Display	
	Energy flow27	
	Multi-information display155	
	Touch screen224	
	Trip information156	
	Warning message500	
	Warning message500 Do-it-yourself maintenance414	
	Warning message	

	Doors	Engine
	Door lock35, 47, 50	ACCESSORY mode139
	Rear door child protector51	Compartment420
	Driver's seat belt reminder light 493	Hood417
	Driver's seat position memory60	How to start the
	Driving	hybrid system138
	Correct posture93	If the hybrid system
	Procedures128	will not start528
	DVD player/changer266	Overheating538
		Power (ignition) switch138
Е	Electric power steering200	Engine compartment cover421
	Electronic key	Engine coolant temperature
	If the electronic key does	gauge148
	not operate properly531	Engine/power control unit coolant
	Replacing battery454	Capacity548
	Emergency, in case of	Checking427
	If a warning light turns on491	Preparing and checking
	If a warning message is	before winter215
	displayed500	Engine oil
	If the electronic key does	Capacity547
	not operate properly531	Checking422
	If the hybrid system	Preparing and checking
	will not start528	before winter215
	If the shift lever cannot be	Engine oil maintenance data 425
	shifted from "P"529	Event data recorder489
	If the 12 volt battery is	
	discharged534 <b>F</b>	First-aid kit storage belt
	If you have a flat tire517,527	Floor mats
	If you lose your keys530	Fluid
	If you think something is	Brake429
	wrong488	Washer434
	If your vehicle becomes stuck541	Fog lights
	If your vehicle needs to be	Switch161
	towed482	Wattage552
	If your vehicle overheats538	Foot light352
	Energy monitor27	

	Front passenger occupant	
	classification system	107
	Front passenger's seat belt	
	reminder light	. 493
	Front seats	
	Adjustment	58
	Driver's seat position memory .	60
	Front turn signal lights	
	Wattage	552
	Fuel	
	Capacity	546
	Fuel gauge	148
	Gas station information	596
	Information	553
	Refueling	83
	Messages	511
	Fuel door	83
	Fuel filler door	83
	Fuses	456
G	Garage door opener	377
	Gas station information	. 596
	Gauges	148
	Glove box	
Н	Hands-free system	
	(for cellular phone)	306
	Head restraints	
	Headlight aim	
	Headlight cleaner	
	5 - 2 - 2 - 2 - 2 - 2 - 2 - 2 - 2 - 2 -	

Headlights	
Adaptive front lighting system	159
Discharge headlights	
precautions	.479
Replacing light bulbs	474
Switch	158
Wattage	552
Heaters	
Seat heaters	.369
Side mirror	.240
Hill-start assist control	200
Hood	417
Hooks	
Cargo	375
Shopping bag	375
Hybrid system	22
Emergency shut off system	27
Energy monitor/consumption	
screen	27
High voltage components	26
Power meter	148
Power (ignition) switch	138
Identification	
Engine	.545
Electric motor	.545
Vehicle	.545
Ignition switch	
Power switch	138
Illuminated entry system	.352
I/M test	413
Immobilizer system	88
Indicator lights	152

Initialization

Items to initialize ......575

	Instrument panel light control	149	М	Maintenance	
	Interior lights			Do-it-yourself maintenance	414
	Interior lights	353		General maintenance	410
	Wattage	552		Maintenance data	544
	Intuitive parking assist			Maintenance requirements	408
	, ,			Meter	
J	Jack			Instrument panel light control	149
	Positioning a floor jack	418		Meters	
	Replacing the wheel			Micro dust and pollen filter	236
	Jack handle			Mirrors	
				Inside rear view mirror	74
K	V	47		Side mirror heater	240
IX	Keyless entry	4/		Side mirrors	75
	Keys			Vanity mirrors	363
	If the electronic key does	F.21		Moon roof	
	not operate properly			MP3 disc	262
	If you lose your keys			Multi-information display	
	Key number plate				
	Keys		0	Odometer	148
	Mechanical key			Oil	1 10
	Power (ignition) switch			Engine oil	422
	Wireless remote control ke	ey4/		Opener	122
				Fuel filler door	83
L	Lexus Link System	38/		Hood	
	Light bulbs			Trunk	
	Replacing			Outer foot lights	
	Wattage			Outside rear view mirrors	
	Light sensitive optitron meter	150		Adjusting and folding	75
	Lights			Mirror position memory	
	Fog light switch			Outside temperature	
	Headlights switch			display	365
	Interior lights list			Overhead console	
	Replacing light bulbs			Overheating, Engine	
	Turn signal lever			C TOTTICATING, ETIGITIC	
	Vanity lights				
	Wattage	552			

Р	Parking brake	147
	Parking lights	
	Replacing light bulbs	474
	Switch	158
	Wattage	552
	Personal lights	354
	Power meter	148
	Power outlet	368
	Power windows	77
	Pre-collision system	206
R	Radar cruise control	160
	Radiator	
	Radio	
	Radio data system	
	Rear sunshade	
	Rear turn signal lights	37 Z
	Replacing light bulbs	171
	Wattage	
	Rear view monitor system	
	Rear window defogger	
	Replacing	Z+O
	Electronic key battery	151
	Fuses	
	Light bulbs	
	Reporting safety defects for	7/ 7
	U.S. owners	578
	O.J. OWHEIS	57 0
S	Seat belts	
	Adjusting the seat belt	66
	Automatic locking retractor	68
	Child restraint system	
	installation	117
	Cleaning and maintaining	
	the seat belts	406

Emergency locking retractor	68
How to wear your seat belt	
How your child should wear	
the seat belt	69
Pre-collision seat belts	
Pregnant women,	
proper seat belt use	68
Reminder light	
Seat belt extenders	
Seat belt pretensioners	
Seat heaters/ventilators	
Seating capacity	
Seats	
Adjustment	58
Adjustment precautions	59
Child seats/child restraint	
system installation	117
Cleaning	
Driver's seat position memory.	60
Head restraint	
Properly sitting in the seat	93
Seat heaters	
Service reminder indicators	152
Shift lever	
If the shift lever cannot be	
shifted from P	529
Transmission	142
Shift lock system	529
Shopping bag hooks	375
Side airbags	95
Side marker lights	
Switch	158
Side mirror	
Adjusting and folding	
Mirror position memory	60

Smart access system with	
push-button start	
Antenna location	
Entry function	35
Starting the	
hybrid system	138
Spare tire	
Inflation pressure	
Spare tire	
Spark plug	
Specifications	
Speedometer	148
Steering wheel	
Adjustment	
Audio switches	303
Steering wheel position	
memory	60
Storage compartment	
Storage feature	355
Storage teatureStuck	355
_	
Stuck  If your vehicle becomes stuck  Sun visors	541
Stuck  If your vehicle becomes stuck  Sun visors	541 <b>362</b>
Stuck  If your vehicle becomes stuck  Sun visors  Switch  Fog light switch	541 <b>362</b> 161
Stuck  If your vehicle becomes stuck  Sun visors  Switch  Fog light switch  Ignition switch	541 <b>362</b> 161
Stuck  If your vehicle becomes stuck  Sun visors  Switch  Fog light switch  lgnition switch	541 362 161 138
Stuck  If your vehicle becomes stuck  Sun visors  Switch  Fog light switch  Ignition switch  Light switches  Mode select switch	541 362 161 138 158
Stuck  If your vehicle becomes stuck  Sun visors  Switch  Fog light switch  lgnition switch	541 362 161 138 158
Stuck  If your vehicle becomes stuck  Sun visors  Switch  Fog light switch  Ignition switch  Light switches  Mode select switch	541 161 138 158 143
Stuck  If your vehicle becomes stuck.  Sun visors  Switch  Fog light switch  Ignition switch  Light switches  Mode select switch  Power door lock switch	541 362 161 138 143 50 138
Stuck  If your vehicle becomes stuck.  Sun visors	541 362 161 158 143 50 50
Stuck  If your vehicle becomes stuck.  Sun visors	541 362 161 158 143 50 50
Stuck  If your vehicle becomes stuck.  Sun visors	541 161 138 158 143 50 138 77
Stuck  If your vehicle becomes stuck.  Sun visors	54116115815813850
Stuck  If your vehicle becomes stuck.  Sun visors	5413621611381435077436438

_
Tachometer148
Tail lights
Switch158
Theft deterrent system
Alarm90
lmmobilizer system88
Theft prevention labels92
Tire inflation pressure551
Tire information
Glossary562
Size559
Tire identification number558
Uniform Tire Quality Grading560
Tires
Chains216
Checking435
Compact spare tire518
lf you have a flat tire517, 527
Inflation pressure551
Information556
Replacing517
Rotating tires435
Size551
Snow tires218
Tire pressure warning system 435
Tools517
Total load capacity214
Touch screen224
Towing
Dinghy towing221
Emergency towing482
Trailer towing220
Traction control200

	Transmission	
	If the shift lever cannot be	
	shifted from "P"	529
	Mode select switch	143
	"S" mode	144
	Transmission	142
	Trip meter	148
	Trunk	
	Opener	55
	Trunk light	56
	Wattage	552
	Turn signal lights	
	Replacing light bulbs	474
	Switch	146
	Wattage	552
٧	Vanity lights	
	Vanity lights	363
	Wattage	552
	Vanity mirrors	363
	Variable gear ratio steering	201
	Vehicle dynamics	
	integrated management	201
	Vehicle identification number	545
	Vehicle load limits	214
	Vehicle stability control	200
	Ventilators	369
W	Warning buzzers	
	Brake system	491
	Downshifting	145
	Open door	493
	Seat belt reminder	493

Warning lights	
Anti-lock brake system	492
Brake system	491
Charging system	491
Electric power steering	
warning light	492
Electronically	
controlled brake system/	
Vehicle stability control	492
Low fuel level	493
Malfunction indicator lamp	492
Master warning light	494
Open door	493
Pre-collision system	492
Seat belt reminder light	493
SRS airbags	492
Tire pressure warning light	493
Warning messages	
Anti-lock brake system	504
Brake assist	504
Dynamic radar	
cruise control	502
Engine oil level	507
Engine oil maintenance	507
Engine oil pressure	500
Headlight	501
Hill-start assist control	504
Hood	505
Hybrid system5	00, 509
Intuitive parking	
assist502,	508, 512
Moon roof	506
Open door	505
Parking brake	506
Pre-collision system5	502, 508
Refueling	511

Rear lights system	501
Smart access system with	
push-button start	513
Steering lock	
Tire pressure warning	
system	.501, 507
TRAC	504
Trunk	506
VGRS	504
VSC/ECB	504
Washer fluid	506
Washer	
Checking	434
Preparing and checking	
before winter	215
Switch	162
Washing and waxing	402
Weight	
Cargo capacity	210
Load limits	214
Weight	544
Wheels	449
Window glasses	77
Window lock switch	50
Windows	
Power windows	77
Rear window defogger	240
Washer	162
Windshield wipers	
Position	217
Windshield wipers	162
Winter driving tips	215
Wireless remote control key	
Locking/Unlocking	47
Replacing the battery	454
WMA disc	